

Instructions for 1/2 wave home base antenna

- 1, Unpack aerial from box.
- 2, Tip aerial upside down to release aluminium tubes.
- 3, Take out the three 5mm screws and nuts from self-seal bag place through black plastic moulding, fasten with screw driver
- 4, Now you are ready to assemble antenna. Holding the base of the antenna and pass the 22 mm tube inside the 25 mm tube until you reach the black mark about 60mm, slip over the correct size jubilee clip and tighten with a screw driver. Repeat this process with remaining tubes, the black mark for remaining tubes is 50 mm. Do not forget to push on end cap provided.
- 5, Using the u bolts provided attach base of antenna to a mounting pole (not provided)
- 6, You are now ready to mount your antenna.
- 7, To adjust SWR undo bottom jubilee clip and move pole to correct SWR.

Manufactured by

www.sigmaeurocomm.co.uk

